

Factory Wheel with ididit's E-Body Steering Wheel Adaptor

For Part Number's 2209320020, 2209320030, 2209320040, 2209320051



Figure 1



Figure 2



Figure 3



Figure 4



Figure 5

1. Check to verify the driving wheels are straight. On top of the column there is a white horn tube sticking up. If it is not already, this tube should be rotated to the 10 - 12 o'clock position when the driving wheels are straight (**Figure 2**). Set the adaptor on the shaft of the column, this may require you to rotate the adaptor slightly to the closest tooth on the spline.
2. Install the 9/16 nut and torque to 35 FT. LBS.
3. Install the horn wire by aligning the catch pin and push in, then turn 1/8 of a turn clockwise. (**Figure 3**)
4. Now use the three provided bolts to install the wheel.
5. Use the original three screws that held the horn mechanism in place to re-secure it. (**Figure 4**)
6. Now connect the wire to the electrical tab, and finally push the button over the contact.

Aftermarket Replacement Wheels:

If using the Grant Tuff Grip aftermarket replacement wheel, with our adaptor, you will need these additional parts for your horn to function properly. (**Figure 5**) We have a kit that includes all of these components. Kit part number is: 2611010010

If you have any questions about installation you can contact ididit's tech line and we will be happy to walk you through any of the processes. Call (517) 424-0577 or visit us online and click "Contact Us".



www.ididitinc.com

ididit inc. 610 S. Maumee St. 49286 Tecumseh, MI PH: 517-424-0577 FAX: 517-424-7293