

1964-66 Mustang Floor Mount Installation Instructions

For Part #'s 2400010010

1965-66 Mustang Floor Mount:

First slide the clamp up the column. You may want to wrap tape around the bottom of column so you don't scratch it during the installation. Next, slide the metal Floor Mount onto the column with the tabs facing upward. Then slide the gasket onto the column. Once you have your column in place tighten the Floor Mount & Gasket to the floor. You can then tighten the clamp around the column and the Floor Mount tabs.



***PLEASE NOTE:** The enclosed floor mount has a “hot dip” black oxide finish. It would be important to put a permanent finish on it before you install this floor mount.



ididit inc. 610 S. Maumee St. 49286 Tecumseh, MI • PH: 517-424-0577 • FAX: 517-424-7293 • ididitinc.com
Instruction #: 8000010215 REV 12/12