



STREET DEMON BILLET THROTTLE CABLE BRACKET P/N 1958

INTRODUCTION:

Demon™ Carburetion has written this manual for the installation of the **Billet Throttle Cable Bracket**. This manual contains all the information needed to install this product. Should you need information or parts assistance, please do not return the unit to the store without first contacting technical service at 1-270-901-3346, Monday through Friday, 7 a.m. to 5 p.m. Central Time. By using this number, you may obtain any information and/or parts assistance that you may require. Please have the part number on hand of the product you purchased when you call technical service.

NOTE: This bracket utilizes a square GM style throttle cable.

INSTALLATION:

1. Mount the brackets utilizing both the front and rear carburetor studs on the left side. The brackets are designed to mount only one way.
2. Mount the front spring holder and the rear cable holder, leaving the screws slightly loose for final adjustment.
3. Installing the throttle arm return spring bracket: Demon™ P/N 1952 is required and is included with this kit. See P/N 1952 for installation instructions on that bracket.
Method—capture the carburetor throttle arm between the outer hat and inner “L” shape spring bracket using a 1/4” x 28 bolt supplied with a drop of RED LOCTITE on the threads.

CAUTION: Allow Loctite to dry prior to use.

4. Install the return springs and set the desired tension. Position the cable for full throttle remembering to tighten the screws.

WARNING: Check for cable bind before starting or driving the vehicle.

LIT730

1-270-901-3346

Date: 2-27-13



STREET DEMON BILLET THROTTLE CABLE BRACKET P/N 1958

INTRODUCTION:

Demon™ Carburetion has written this manual for the installation of the **Billet Throttle Cable Bracket**. This manual contains all the information needed to install this product. Should you need information or parts assistance, please do not return the unit to the store without first contacting technical service at 1-270-901-3346, Monday through Friday, 7 a.m. to 5 p.m. Central Time. By using this number, you may obtain any information and/or parts assistance that you may require. Please have the part number on hand of the product you purchased when you call technical service.

NOTE: This bracket utilizes a square GM style throttle cable.

INSTALLATION:

1. Mount the brackets utilizing both the front and rear carburetor studs on the left side. The brackets are designed to mount only one way.
2. Mount the front spring holder and the rear cable holder, leaving the screws slightly loose for final adjustment.
3. Installing the throttle arm return spring bracket: Demon™ P/N 1952 is required and is included with this kit. See P/N 1952 for installation instructions on that bracket.
Method—capture the carburetor throttle arm between the outer hat and inner “L” shape spring bracket using a 1/4” x 28 bolt supplied with a drop of RED LOCTITE on the threads.

CAUTION: Allow Loctite to dry prior to use.

4. Install the return springs and set the desired tension. Position the cable for full throttle remembering to tighten the screws.

WARNING: Check for cable bind before starting or driving the vehicle.

LIT730

1-270-901-3346

Date: 2-27-13