



Installation Diagram

81068

1964-74 CHEVROLET CHEVELLE & 1967-74 CHEVROLET CAMARO SBC ENGINE*

*Using factory stock Chevrolet 3-bolt manifolds.
This kit will not work with heat riser.
It does NOT fit "Ram Horn" style manifolds or
1962-67 Nova or X-Frame Impalas.

