

CLUTCH FORK BOOT – 15510 (Chevy) & 15515 (Mopar)

DIRECTIONS FOR APPLYING ADHESIVE

Please apply adhesive (not included – E6000® or equivalent) to the boot before putting the boot into the bellhousing. Simply apply adhesive into the sealing U-Channel in the rubber clutch fork boot. This will ensure sealing to keep out moisture and debris from your clutch.

97140095

Date: 12-1-17